

		NO. OF
PART #	DESCRIPTION	PARTS
381	Crankcase	1
382	Ball Bearing	1 2 2 2 2 1 1 1 1 1 8
	Bearing Cover	2
	Gasket	2
384	Crankshaft Oil Seal	2
	Oil Filler Cap	1
	Oil Cap Gasket	1
	Piston Cover	1
388	Back Cover	1
389	Back Cover Gasket	1
3810	Back Cover Screws	8
3811	Oil Gauge Window	1
3812	Bearing Cover Screws	12
3813	Pulley Key	1
3814	12" Pulley	1
3815	Set Screw	2
3816	Pump Rail	2
3817	Bolt & Washer	4
	Crankshaft	1
	Connecting Rod Complete	3
	Piston Pin	- 3
	Piston	3
	Piston Wiper	3
	Oil Plug & Washer	2
	Crankcase Nut & Washer	4
3829	Piston Seal	3
3830	Gland Nut	3
	Piston Chamber	1 3 3 3 3 2 4 3 3 1 3 6
	Grease Cup	3
3837A	Complete Valve	
3837B	Valve O Ring	12
3837C	Valve Cover	6
3837D	Valve Spring Seat Valve Spring	6
3837E	Valve Disc	6
3837F	Valve Seat	6
3838	Suction Chamber	6
3841	Gauge O to 1000 PSI	1
3842	Air Chamber	1
3842A	Air Chamber Gasket	1
3842B	Chamber Nut & Washer	2
3843	Complete Control Valve	1
3843A	Pressure Adjusting Cap	1
3843B	Upper Spring Seat	1
3843c	Spring	1
3843D	Lever	i
3843F	Retaining Bolts - S.S.	2
		-

PART #	DESCRIPTION	NO. 0
3843G	Lower Spring Seat	1
3843H	Seat Pin	1
3843J	Spring Case	
3843K	Control Spindle	1
3843L	Spindle Cage	1
3843M	Diaphragm	1 1 1 1 1 1
3843P	Control Ball	1
3843T	Seat Packing	1
3843V	Control Seat	1
3843X	Control Seat Case	1
3843Y	Control Stop	1
3843Z	Control Case O Ring	1
3844L	Chamber Bolt & Washer	
	(long)	2
3844S	Chamber Bolt & Washer	
	(short)	2
3850	Crankcase Studs	4
3851	Chamber Studs (long)	2
3860	Packing Kit	1
3860B	Buna-N Flange	2 1 3 3
3860c	Grease Ring	3
3860E	Buna-N V-Packing	24
3860G	Bottom Adaptor	3
3880	Needle Valve	1
3890	Belt Tension Bolt	2
3892	Discharge Chamber	1
38100	Crankshaft Protector	1
38101	Crankshaft Protector	
	Screws	3

WARRANTY

* Based on the logical assumption that manufacturing and
* material deficiencies will manifest themselves within 90
* days time, all M38E power sprayers are guaranteed 90 days
* from date of purchase, by the original purchaser, against
* defective material and workmanship (but not against dam-
* age or wear caused by misuse, abrasion, negligence,
* accident, faulty installation, or tampering in a manner
* to impair its normal operation) when the equipment is in-
* stalled and operated in accordance with factory recommen-
* dations and instructions.
*

* All such defective parts will be repaired or replaced
* free of charge if returned prepaid to the factory or
* authorized service depot. In all cases within the guar* antee period where examination indicates damage due to
* causes other than defectiveness repairs will be made at a
* reasonable charge.